



INSTALLATION INSTRUCTIONS

Part Number: YA-1219

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

* FREE K&N® decal To register your warranty, please see us online at knfilters.com/register. FREE K&N® decal *

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

INSTALLATION:

1.) Remove the OE filter from airbox by removing the 4 screws retaining the airbox lid. Once removed, pull out the o-ring from the air filter housing lid. (Fig.1 - 3)

2.) Remove the dirty air filter from housing. (Fig.4)

NOTE: remove any dirt or debris that may be present in the filter housing.

3.) Once filter has been removed, pull out the o-ring from the air filter housing. (Fig.5)

NOTE: The 2 o-rings for the OE filter will NOT be used with the K&N air filter.

4.) Install the K&N air filter into the air filter housing.

5.) Reverse steps 1 & 2 to complete the air filter installation.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5



Fig. 6

CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.